


Anechoic Chamber Antenna Range Axes



Axis 4: AUT Polarization
Positive is clockwise
defined looking at front of
platter (so opposite for Tx
and AUT platters, which
face each other).

Axis 1: AUT Azimuth
Positive is clockwise
looking down from
above.

Axis 5: Tx Polarization
Positive is clockwise
defined looking at front of
platter (so opposite for Tx
and AUT platters, which
face each other).